

Adjustment Program for Stylus C40UX / C40SX / C20UX / C20SX Operating Instructions

1. Operating Environment:

- Windows95 OSR2.0 or higher and Windows98.

- (for Windows95)
LPT1-LPT3 are used.
- (for Windows98)
LPT1-LPT3 and EPUSB1-EPUSB3 are used.

2. How to use the Adjustment Program:

Copy the Adjustment Program on the desktop, and then , execute the program.

3. Cautions:

- 1) When you confirm the function of USB port properly, you must use Windows98 pre-installed PC. It cannot function properly on Windows95.

- 2) When you operate this program on the Windows95 or Windows98, you cannot operate it with Status Monitor is running. Close Status Monitor on Task tray before start the Adjustment Program.

- 3) Do not change the setting for "Font size" in "settings tab" of the "Display Property" window.

- 4) Please do not start the Adjustment Program before connecting the printer with a parallel I/F cable or USB I/F cable.
If you do not follow the instruction, the program will freeze.

- 5) Please do not send any commands during Check Pattern printing.

- 6) In case of turning off the printer, or the parallel I/F cable or USB I/F cable is removed during booting the Adjustment Program, please restart the Adjustment Program.

- Over -